



Electric and gas cooking surfaces

This appliance complies with the eco-design requirements of Regulation (EU) No. 65/2014, which supplements Directive 2010/30/EU, in accordance with EN 60350-2, EN 15181 and EN 50564.

ENERGY SAVING TIPS

Make the most of your hot plate's residual heat by switching off cast iron hot plates 10 minutes before the end of your cooking time and glass ceramic hot plates 5 minutes before the end of cooking time.

The base of your pot or pan should cover the hot plate. If it is smaller, precious energy will be wasted and pots that boil over leave encrusted remains that can be

fife base of your bot of pair should cover the hot plate. In it is smaller, precious energy will be wasted and bots that boll over leave enclusted remains that can't difficult to remove.

Cook your food in closed note or nane with well-fitting lide and use as little water as possible. Cooking with the lid off will greatly increase energy consumption.

Cook your food in closed pots or pans with well-fitting lids and use as little water as possible. Cooking with the lid off will greatly increase energy consumption Use purely flat pots and pans

If you are cooking something that takes a long time, it's worth using a pressure cooker, which is twice as fast and saves a third of the energy.

Product information complies with Commissi	ion Delegated Regulation (EU)	No. 66/2014	
·	Symbol	Value	Unit
Identification of the model	KCG 4380 W Turbo		
Type of surface cooking	Gas – glass		
Number of cooking zones and/or areas		3	
Heating technology (induction cooking zones and cooking zones)	oking areas, radiant cooking z	ones and solid plate)	
Rear left		X	
Rear centre		X	
Rear right		X	
Centre left		X	
Centre centre		X	
Centre right		X	
Front left		X	
Front centre		X	
Front right		X	
For circular cooking areas: diameter of the usef	ul surface area for electrically-		
Rear left	Ø	X.X	cm
Rear centre	Ø	X.X	cm
Rear right	Ø	X.X	cm
Centre left	Ø	X.X	cm
Centre centre	Ø	X.X	cm
Centre right	Ø	X.X	cm
Front left	Ø	X.X	cm
Front centre	Ø	X.X	cm
Front right	Ø	X.X	cm
For non-circular cooking areas: length and width of the			
Rear left	L Width	X.X / X.X	cm
Rear centre	L Width	X.X / X.X	cm
Rear right	L Width	X.X / X.X	cm
Centre left	L Width	X.X / X.X	cm
Centre centre	L Width	X.X / X.X	cm
Centre right	L Width	X.X / X.X	cm
Front left	L Width	X.X / X.X	cm
Front centre	L Width	X.X / X.X	cm
Front right	L Width	X.X / X.X	cm
Energy consumption for cooking			140.00
Rear left	EC electric cooking	X.X	Wh/Kg
Rear centre	EC electric cooking	X.X	Wh/Kg
Rear right	EC electric cooking	X.X X.X	Wh/Kg
Centre left	EC electric cooking		Wh/Kg
Centre centre	EC electric cooking	X.X	Wh/Kg
Centre right	EC electric cooking	X.X	Wh/Kg
Front left	EC electric cooking	X.X X.X	Wh/Kg
Front right	EC electric cooking	X.X X.X	Wh/Kg
Energy consumption for cooking zone or area, calculated per kg	EC electric cooking EC electric cooking	X.X	Wh/Kg Wh/Kg
Energy consumption for cooking zone of area, calculated per kg	surface	۸.۸	WII/Ng
Number of gas-powered burners	Surface	3	
Energy efficiency	for gas burner	ŭ	
Rear left	EE gas burner	X.X	
Rear centre	EE gas burner	54.1%	
Rear right	EE gas burner	X.X	
Centre left	EE gas burner	X.X	
Centre centre	EE gas burner	X.X	
Centre right	EE gas burner	53.5%	
Front left	EE gas burner	X.X	
Front centre	EE gas burner	X.X	
Front right	EE gas burner	X.X	
Energy efficiency for the gas cooking surface	EE gas cooking	53.5%	
- 5,	surface	JJ.J /0	